

Touchscreen Quick Guide

How to turn your CommBox LED Touchscreen on/off


1. Press the red **Power** button on the top left hand side of your remote, to switch on your CommBox LED Touchscreen.
2. Press the same **Power**

How to select/change between sources on your CommBox Touchscreen

1. To select a source, first press the top right **Source** button on your remote. This will bring up the Input Menu (pictured right).
2. Use the **Up** and **Down** arrows in the centre of the remote to move up and down to highlight your source.
3. Press **OK** to select your chosen source.

How to connect your CommBox LED Touchscreen

1. Connect your laptop or PC to an **HDMI**, **DVI** or **VGA** port as appropriate.
2. For **VGA** or **DVI**, you will also need to connect audio output to **PC Audio**.
3. Connect **USB** cable to the laptop you will be using with the touch system.
4. Connect external passive speakers using 3.5mm mono plug to **Spkr Out**.
5. A DVD or VCR player may be connected using the **Component** input.



commBOX.com.au

Touchscreen Quick Guide

How to turn your CommBox LED Touchscreen on/off


1. Press the red **Power** button on the top left hand side of your remote, to switch on your CommBox LED Touchscreen.
2. Press the same **Power** button again to switch it off.

How to select/change between sources on your CommBox Touchscreen

1. To select a source, first press the top right **Source** button on your remote. This will bring up the Input Menu (pictured right).
2. Use the **Up** and **Down** arrows in the centre of the remote to move up and down to highlight your source.
3. Press **OK** to select your chosen source.


How to connect your CommBox LED Touchscreen

1. Connect your laptop or PC to an **HDMI**, **DVI** or **VGA** port as appropriate.
2. For **VGA** or **DVI**, you will also need to connect audio output to **PC Audio**.
3. Connect **USB** cable to the laptop you will be using with the touch system.
4. Connect external passive speakers using 3.5mm mono plug to **Spkr Out**.
5. A DVD or VCR player may be connected using the **Component** input.




commBOX.com.au

Touchscreen 4K



commBOX.com.au

Touchscreen 4K



commBOX.com.au